

LT350-OEM BELT SCALE

Quick Reference Guide





REV 5..00

INDEX

LT350BSI BELT SCALE SPECIFICATION	11
LT350BSI KEYBOARD FUNCTIONS	14
SCALE DISPLAY INDICATORS.....	15
LT350 HARDWARE INTERFACE DIAGRAM	16
HOW TO NAVIGATE THE INTEGRATOR MENU FUNCTIONS.....	17
LT350BSI BELT SCALE CONFIGURATION OPTIONS	18
HOW TO SET INTEGRATOR PARAMETERS – PART 1	19
HOW TO DO A STATIC BELT SCALE CALIBRATION	22
HOW TO INSTALL AND CONNECT A SUMMING BOX.....	23
SCALE IDLER ASSEMBLY.....	24
HOW TO INSTALL THE WEIGH IDLER	25
LT45SS SCALE SPEED SENSOR ASSEMBLY	26
HOW TO WIRE THE SPEED SENSOR	27
HOW TO CALIBRATE THE SPEED SENSOR	28
HOW TO PERFORM IDLER LOAD CELL ADJUSTMENTS	29
LT350BS SCALE LOAD CELL DIAGNOSTICS	31
HOW TO USE THE DATA LOG FUNCTION	32
HOW TO PRINT DATA LOG REPORTS.....	33
HOW TO CONFIGURE THE TOTALIZER PULSE OUTPUT.....	34
HOW TO CONFIGURE THE TOTALIZER PULSE OUTPUT.....	35
HOW TO CONFIGURE THE INTERNAL CURRENT LOOP OUTPUT	36
HOW TO WIRE THE INTERNAL CURRENT LOOP OUTPUT TO A PLC	38
HOW TO CONFIGURE SET POINT PARAMETERS	40
HOW TO WIRE THE SET POINT INTERFACE	41
HOW TO TRIM A SUMMING BOX	42
LT350BSI BELT SCALE - SENSE LINE MODE.....	43
HOW TO SETUP MULTIPLE WEIGH IDLERS TO SINGLE CHANNEL	44
HOW TO SETUP SERIAL RS232 TO TRANSMIT WEIGHT DATA	45
HOW TO SETUP RS485 TO TRANSMIT WEIGHT DATA.....	46
HOW TO SET SCALE FILTER PARAMETERS.....	49




LT350 BELT SCALE OEM MODULE




LT350 BSI OEM BELT SCALE INTEGRATOR – PANEL MOUNT

LT350 MODULE

measurements - mm




**KEYPAD
OUTLINE**




LT350 OEM PANEL CUTOUT 1:1

LT350 BSI OEM BELT SCALE SCREW TERMINALS – STANDARD MODE



LT350 BSI OEM BELT SCALE SCREW TERMINALS – SENSE LINE MODE



LT350BSI BELT SCALE SPECIFICATION

LT350BSI Belt scale weight integrator and belt speed input

PLC Output Options Programmable 4-20mA and Totalizer Pulse Output

Belt Scale Functions Material Rate, Belt Speed (fixed or variable), Totalizer and statistical data logging plus a batch set point controller

Accuracy ± 0.5 to 2% over 4 to 1 weigh idler span, e.g. 2 weigh idlers = 1.5% accuracy

Belt Width Universal

Belt Speed Dynamic speed up to 50 feet per second using belt speed sensor

Sampling Rate 1-500Hz, software selectable

Span Stability 2.5ppm/ Celsius

Zero Stability 6nV/Celsius

Calibration Method Calibration through software menu system

Filtering Programmable response filtering

Firmware Upgrading In field Firmware upgrading using serial or Ethernet

Unit Conversion Lb/kg/T/TN

Display Full Graphics LCD display (White on Blue)

Scale Input ranges 20mV range

Load Cell Excitation 5VDC, 8x350, 16x700 ohm in total

Serial Ports 1 or 2 full duplex RS232/RS485

Ethernet TCP/IP Wifi socket server - optional

Power 24VDC 300mA nominal

Temperature Range -10°C to +40°C (14°F to 104°F)

LT350-BSI-xPSxx Stainless Steel Panel Mount

LT350-BSI-xNDxx Aluminum NEMA4 wall mount (internal 110-240AC power supply included)

Operating Class Class III/IIIL @10 000div

GENERAL CALIBRATION SETUP REFERENCE


The belt integrator runs automatically at startup. To exit the belt scale run-mode press **STOP** repeatedly until prompted to exit to calibration mode – use the **MENU** key to navigate parameters. Once in calibration mode, press F1 to save changes to parameters and START to run the belt scale integrator.

DEFAULT FACTORY PASSWORD:

There are close to a hundred parameters that can be set entering calibration mode and then simply by press the **MENU** key to list and navigate the parameter of interest using the up/down arrow keys.

Protecting important settings from unauthorized tampering is a valuable feature and as such, most calibration and setup parameters are protected by a password. The password only needs to be entered once and only after the **F1** key was pressed to save settings during the last session. Once the **F1** key was pressed in calibration mode to save the new settings, calibration mode will be exited and to enter calibration mode again, the user needs to enter the password again if the password function was enabled.

The factory password is [1234]. It is recommended that the user change this password to a unique 4 number combination in order to protect the integrity of the system scale calibration and settings using **COMMAND[98]** in the menu parameter list.

For most commands the user only needs to enter calibration mode once by providing the password where required. 

LEGAL FOR TRADE APPLICATIONS:

Some parameters are protected by a password – which might be a government requirement for applications that will use the scale for trading to the public by weight. Such applications require an audit trail history of parameter changes and settings.

NON LEGAL FOR TRADE APPLICATIONS:


Many industrial applications are strictly used for process control such as batching and monitoring weight. These types of implementations do not require legal for trade certification or inspection by government agencies.

IMPORTANT!!!

It is important to note that no settings are saved in calibration mode until the user presses the F1 key

Scale Handling

Observe the following precautions when handling the scales. Once the scale is installed on the idler frame, the weigh assembly becomes a very sensitive measuring instrument. Hitting the weigh idler assembly with a hammer or pressing against the weigh idler forcefully will damage the load cells.



- Do not pry on the weigh idler or the load cells directly.
- Do not stand or lean on the weigh idler scale.
- Lift the scale by the weigh blocks only. Do not lift the scale by the idler or idler mounting brackets.
- Never subject the scale to sudden impacts or shocks.

Power Supply Requirements

It is important to note that in very noisy industrial environments, power-conditioning filters would be a requirement to ensure a failsafe operation under all conditions. Indicators should not share AC power with electrical motors and switchgear. Consult with the site engineer for clean AC power.

LT350BSI KEYBOARD FUNCTIONS



UNITS switch between lb and kg. Units can also be locked at startup.



ZERO scale can be done with no motion and with the weight within the user programmable zero range. There is also an auto-zero function available.



TARE scale can be done with a positive weight on the belt scale.



GROSS or NET weight display based on a tare entry. The belt scale total can be tared by simply pressing the Tare key and cleared by pressing the CLEAR key



MENU key is the main parameter navigation key. Once selected the user can use the up/down keys to navigate through all the parameters followed by an **ENTER** key and possibly a password.



ENTER key will execute last command. Use the menu navigation keys to select a parameter followed by the **ENTER** key



CLEAR key can be used to clear entry field or exit the menu mode. To clear current tare entry for belt scale.



Menu navigation key (single line scroll) and numeric up dial.



Menu navigation key (single line scroll) and numeric down dial.



Menu navigation key or speed scroll – up.



Menu navigation key or speed scroll – down.




Menu navigation keys - used to select a menu item and numeric dialing.



SF special function key used to switch between alphanumeric key entry

SCALE DISPLAY INDICATORS



BELT SCALE 99

Belt Scale network ID. If remote control is enabled this will be used to communicate with the unit.



Run state. If batch set point IO control is enabled, the START and STOP keys will control the run state of the system.



Indicates batch IO control is enabled active or idle



Indicates that the special function key **SF** was pressed to select either lower or upper case characters for user input where applicable




Indicate Weight stabilized

NET/GROSS

Indicate weigh mode NET or GROSS. A tare weight must be set.



Indicate scale at zero weight - center of zero




Indicate current units selected either kilograms or pounds



This icon indicates that the user changed calibration parameters and to save those parameters the user should end calibration by pressing the **F1** key.

LT350 HARDWARE INTERFACE DIAGRAM



① PWR ⑤

Power supply input. The indicator accepts a dc voltage of 24 DC Volts. Nominal power input should be 24Vdc @ 500mA

NETWORK

SENSE LINE MODE CH1-2

The sense line mode is a special 6 wire load cell configuration. This configuration uses CH-1 as the sense lines and CH-2 as the weigh idler load cell inputs. This configuration is typically used to improve signal quality over long cable hauls. Command[93] should be used to enable sense line activation.

① CH-1 ⑤

Weigh Idler Load cell channels [1-4]. EXT+/- must be connected to the +5V and GND.

① COM-1 ⑤


The primary serial port can be configured as RS232 or RS422 and supports printing or strings using the ASCII.NET protocol

① COM-2 ⑤

The primary serial port can be configured as RS232 or RS422 and supports printing or strings using the ASCII.NET protocol

HOW TO NAVIGATE THE INTEGRATOR MENU FUNCTIONS


The belt integrator runs automatically at startup. To exit the belt scale run mode, press **STOP** repeatedly until prompted to exit to calibration mode – use the **MENU** key to navigate parameters. Once in calibration mode, press **F1** to save changes to parameters and **START** to run the belt scale integrator.



LT350BSI BELT SCALE CONFIGURATION OPTIONS

The LT350BSI single belt scale controller supports up to [4] weigh idlers. Most users simply use one input with a summing box attached. However up to 4 weigh idlers can be connected directly the belt scale controller for higher accuracy.

BELT SCALE - SINGLE CHANNEL USING SUMMING BOX



Advantages

- Short cable runs
- Easy setup
- Good for summing boxes
- Low cost
- Error < 2%


BELT SCALE - DIGITAL SUMMING



Advantages

- Digital summing x2
- Digital trimming per idler
- Higher Accuracy
- Strong signal
- Individual diagnostics
- Good signal to noise
- Error < 1.5%

BELT SCALE - UP TO 4 CHANNELS DIGITALLY SUMMED FOR HIGHEST ACCURACY




Advantages

- Digital summing x4
- Digital trimming per idler
- Very High Accuracy
- Strong signal
- Individual diagnostics
- Excellent signal to noise
- Best accuracy
- Error < 0.5%

HOW TO SET INTEGRATOR PARAMETERS – PART 1

To set belt scale parameters, press **STOP** to exit the belt scale mode. Once in calibration mode, press the **MENU** key and use the UP/DOWN arrows to navigate to **BELT SCALE SETUP** or **CALIBRATION WIZARD**.

To save changes to parameters once finished, press **F1** once you are back in the main calibration menu.



Idler Allocation Channels [1-4]

This parameter is the number channels allocated to weigh idlers. Typically each weigh idler will be connected to channels 1 up to 4. Each weigh idler has generally two summed load cells. *If you opt for multiple idlers per single channel using a summing box - see section on multiple idlers to single channel.*

Number Of Idlers on Conveyor Belt [1-10]

This parameter will only be active if Idler Allocation was set to [1]. This parameter allows for multiple weigh idlers per single weigh channel e.g. a single channel cable connected to a summing box. *If you opt for multiple idlers per single channel using a summing box - see section on multiple idlers to single channel.*

Idler Spacing

This parameter defines the distance between weigh idlers. All weigh idlers should have the same equal distance between them entered in centimetres. This parameter forms part of the static weigh calibration.

Totalizer Reset

The master totalizer can be reset to zero or pre-set. The system password might be required to unlock this parameter. The totalizer rolls over at 10 million base counts (kg/lb). If the belt data log function is enabled the totalizer will only roll over at midnight with the start of a new day somewhere above 10 million. If the data logger is enabled, changing the totalizer during data logging will invalidate data log values which might require erasing the log data.

Material Test

The Material Test can only be performed once a static weight calibration has been completed and once the belt speed sensor has been installed and calibrated.

The belt scale allows for two calibration methods. Static weight calibration is the easiest method and is a combination of test weights applied to each weigh idler, belt spacing and speed calibration. The second optional calibration method is a Material Test calibration where a known amount of test material is fed on the moving belt scale followed by a correction factor to make the displayed total weight match the test material weighed.

Reset Material Factor

The Material Factor is created as a correction factor once a Material Test calibration has been completed. When this number is at default (1) it indicates that no Material correction is required. The default value is always (1)

Speed Mode

The integrator only supports variable speed mode using a belt speed sensor. If a custom belt speed wheel is used, the user will have to calibrate the speed sensor using the speed calibration setting and speed pulse length.

Speed Pulse Length

If the user selected variable speed mode, the user must enter the distance traveled by the belt in millimeters between two pulses. The factory supplied LT45BSS belt speed sensor wheel has 8 pulses per revolution and with a wheel circumference of 400 millimeters we obtain a pulse length of 50 millimeters. This method can be used to calculate any wheel size with different pulse lengths.

Speed Calibration

This parameter will be used to adjust the calculated speed as indicated. Using the function keys to select the coarseness of the adjustments and adjusting the speed up or down. Once finished, the user must press ENTER to complete the adjustment. Repeat if required.

Speed Time Units

This parameter defines how the belt speed is displayed on the LT350

- Hr. - hour
- Min - minute (default)
- Sec – seconds

Rate Time Units

This parameter defines what unit of time the rate will be displayed in on the LT350.

- Hr. - hour (default)
- Min - minute
- Sec – seconds

Rate Weigh Units

The rate weigh unit parameter defines how the rate is displayed.

- Tn(tonnes) - (default)
- kg/lb

Total Weigh Units

The integrated weigh total units as displayed.

- Tn (tonnes) - (default)
- kg/lb

Tonnes Type Units

The type of tonnes derived from the base weight unit.

- **TN (short ton) - (default)**
- T (metric ton)
- LT (long ton)

Measurement Units

The unit of measure parameter defines how the belt is measured. The default is Ft/Min.

- **Ft - feet (default)**
- M – meters

HOW TO DO A STATIC BELT SCALE CALIBRATION

The belt scale allows for two calibration methods. Static weight calibration is the easiest method and is a combination of test weights applied to each weigh idler, belt spacing and speed calibration. The second optional calibration method is a material calibration where a known amount of test material is fed on the moving belt scale followed by a correction factor to make the displayed total weight match the test material weighed – discussed later.

The static calibration sequence assumes that all the weigh idlers are connected to channels 1 up to 4 of the LT350 Belt Scale Integrator as outlined under configuration options earlier in this guide. Each weigh idler typically has its two load cells paired using a summing box.

To enter calibration mode, the user needs to exit belt scale mode by pressing the STOP key repeatedly until the user is prompted with the option of exiting belt scale mode into calibration mode.

Press **MENU** to navigate to the **CALIBRATION WIZARD** command using the up/down arrows.

The wizard will guide the user through the most relevant parameters. The wizard commands can also be accessed individually under the **BELT SCALE SETUP** menu selection. For new users it would be easier to use the wizard.

The user will also be prompted to enter the belt spacing distance in centimeters. **It is important that the space between each weigh idler be the same distance - this include the weigh idler to static idler spacing.**

The user will be prompted to remove all weights from each weigh idler for to dead load and zero the belt.

The user will then be prompted to attach test weights of equal weight to each weigh idler. The user must then enter the sum of all test weights as the target span weight, e.g. if there are 3 weigh idlers and each idler has a 100kg weight attached. The total weight to enter for the span is 300kg.



This completes the static belt calibration.

The final command asks the user whether to perform a material test calibration – this is optional and should be ignored if only a static weigh calibration is required.

Once the wizard finished, the user can save the new settings by pressing **F1**

To return to belt scale mode press **START**


HOW TO INSTALL AND CONNECT A SUMMING BOX



SCALE IDLER ASSEMBLY

The LT350 support custom scale idler assemblies that requires no modification to the conveyor frame. Custom weigh idler assemblies can be mounted on the conveyor as outlined below – depending on the space requirements and the type of belt scale frame.


However it is very important to note that the spacing distance between the weigh idlers should be exactly the same distance. Static Idler to weigh idler and weigh idler to weigh idler should be the same distance for proper calibration.



HOW TO INSTALL THE WEIGH IDLER

IDLER SPACING AND LOAD CELL PLACEMENT

The capacity of the belt scale is rated on the maximum continuous load that can be carried across any single weigh idler. The maximum capacity per weigh idler should be known prior to determining the components of the scale idler. **It is important that the spacing distance between weigh idlers be exactly equal in length. Static idler to weigh idler and weigh idler to weigh idler should be the same distance for proper calibration.**






LT45SS SCALE SPEED SENSOR ASSEMBLY

The LT45BSS belt speed sensor assembly has a rugged cast iron rubber wheel with sealed bearings incorporated with a magnetic electronic 3 wire speed sensor that interfaces directly with the LT350-BSI integrator. The mounting bracket can easily be tied to a static idler or cross bar.

The belt speed wheel must maintain constant positive contact between the roll and the belt for proper operation. The speed sensor should never come in contact with material that is being conveyed along the belt nor the belt itself. The signal generated by the speed wheel is converted by the integrator into a value that represents belt travel distance.

The LT350-BSI integrator support variable belts speeds using the LT45SS speed sensor assembly or similar setup. The speed sensor is rated up to 50 feet per second.





HOW TO WIRE THE SPEED SENSOR

The LT350-BSI belt scale integrator supports one belt speed pulse sensor input connected to **INPUT[7]** as outlined in the diagram below. The factory supplied LT45SS speed sensor assembly is a 5V, 3 wire device that gets power from the internal 5V supply line on the integrator. LT45SS wheel arm to the cross brace closest to the tail of the conveyor. The wheel assembly must be free to move in the vertical direction and must maintain contact with the belt at all times.

For long distances the speed sensor may be powered by an external 24V DC supply in stead of 5V.

If a constant speed is selected from the belt scale setup menu items, the user should connect INPUT[7] positive to the ground pin.



HOW TO CALIBRATE THE SPEED SENSOR

To set belt speed parameters, press **STOP** to exit to setup mode. Press the **MENU** key and use the UP/DOWN arrows to select **BELT SCALE SETUP**. These parameters need to be set before attempting a material test calibration.

Remember to save changes to parameters once finished using F1 once you are back in the main screen.

STEP 1

Select the belt Speed Mode parameter for variable speed using the LT45-SS belt speed wheel assembly or similar. It will default to variable speed mode.


STEP 2

Connect the belt wheel interface as shown in the speed sensor connection diagram

STEP 3

After the user selected variable speed mode, the user must enter the distance traveled by the belt in millimeters using the belt pulse length parameter under the BELT SCALE SETUP menu. The factory supplied LT45BSS belt speed sensor wheel has 8 pulses per revolution and with a wheel circumference of 400 millimeters we obtain a pulse length of $400/8 = 50$ millimeters. This method can be used to calculate the pulse length for any wheel size with different pulse lengths.

Select the belt speed Calibration parameter in the BELT SCALE SETUP sub menu and while running the belt at a known speed observe the current speed and adjust up or down if so required.




HOW TO PERFORM IDLER LOAD CELL ADJUSTMENTS


This command makes small adjustments to the span factors of each weigh idler channel traditionally done with analog potentiometers. For example, we have a 2 belt scale idler system that was calibrated to 200lb by placing a 100lb weight in the center of each weigh idler. The user then observes that by moving the same weight from one weigh idler to another, that the weight reading is off by a small margin. To correct for this small margins we use menu command – **IDLER ADJUSTMENTS**

- The user then selects the weigh idler channel using keys [1,2,3 or 4] to be adjusted.
- The user then places the test weight on the above selected weigh idler.
- The user adjusts the weight using the F3 & F4 function keys until it reads the same as the test weight on the scale.
- The user then moves to the next weigh idler channel using keys [1,2,3 or 4]
- If this is not the last weigh idler channel repeat by going to step 3.
- The final step is to press **[ENTER]** or **[MENU]** to save or abort the changes made.

This command is only of use in applications with more than weigh idler channels allocated. Place the test weight as close as possible to the center of the weigh idler that is currently selected on the display.



To select the weigh idler channel to be adjusted



These keys select the coarseness of the adjustments



These keys are used to adjust the weight value for the weigh idler channel in question



Press the this key to exit without changes



The **[MENU]** key provides the following options:

- Save and exit
- Abort adjustments
- Reset current load cell channel
- Reset all load cell channels
- Return to adjustment menu

LT350BS SCALE LOAD CELL DIAGNOSTICS

Use the **MENU** key and up/down keys to navigate to **CHECK WEIGH IDLERS** and press **ENTER**



Press these keys to navigate through the weigh idler channel status screens


LOAD CELL STATUS INFORMATION

Cell State :	Runtime diagnostic state of weigh idler or load cell							
	<table><tr><td>PASS</td><td>The weigh idler or load cell , if allocated should be in the [PASS] state</td></tr><tr><td>UNUSED</td><td>If a load cell channel is not allocated using command [3] it should show [UNUSED]</td></tr><tr><td>FAIL</td><td>If a fault is detected with the load cell it will indicate [FAIL]</td></tr></table>	PASS	The weigh idler or load cell , if allocated should be in the [PASS] state	UNUSED	If a load cell channel is not allocated using command [3] it should show [UNUSED]	FAIL	If a fault is detected with the load cell it will indicate [FAIL]	
PASS	The weigh idler or load cell , if allocated should be in the [PASS] state							
UNUSED	If a load cell channel is not allocated using command [3] it should show [UNUSED]							
FAIL	If a fault is detected with the load cell it will indicate [FAIL]							
Raw Counts:	Raw counts pertains to the currently selected load cell or summed weigh idler and is the value before converted to a weight quantity. Raw analog to digital counts can be between [0 – 1000 000] .							
Correction:	Correction is applied in a belt scale that has more than one weigh idler channels. Due to conveyor scale structural factors it is sometimes required to apply corrections to certain weigh idlers channels by using the correction command [15] . The factory default is [1.000]							
Weight:	Display the current weight across all weigh idlers of the belt scale							
Idlers/Scale:	The number of weigh idlers per LT350BSI belt scale with up to 4 weigh idler channels. The scale allocation command [3] is used to allocate the number of weigh idler channels [1-4]							

HOW TO USE THE DATA LOG FUNCTION

The data log function calculates and stores the daily totals for up to 12 months. The data log function is a very useful function to track productivity and the rate of material moved over up to one year. The data log function must first be enabled by accessing calibration parameter **DATA LOG SETUP**. The data log function only works while the integrator is running **[START]**. For best results, the integrator should be permanently powered up, free from power failures and with the integrator running continuously.


Pressing **F1** from the main display of the integrator will plot in real time the last 30 days of daily totals. The user can print the list of daily totals by pressing **PRINT** or **F4**. The user can view any month of the year by pressing the numeric key index of the month on the keypad.



The user can view the daily totals by moving the arrow to the date of interest. The graph indicates that the daily total for 08/05/2012 was 200.5 TN. New data is always added on the right while older data is shifted to the left. A vertical line indicates the month separator. **Press CLEAR to exit the graphics plot function**

The above function allows the user to scroll and display totals of the last 30 days by using the left and right arrows. While in scroll mode the display will flash the cursor and the date to indicate that the currently displayed daily total is historical and not real time. After a 5 second timeout the display will reset itself to displaying the current daily total at the very right side of the screen. The user can view any month of the year by pressing the numeric key index of the month on the keypad.

Pressing **F2** from the above display will allow the user to view and scroll left or right through each monthly total for the last 12 month as indicated by the cursor. The user can press **ENTER** to view the daily total graph of the currently selected month. The user can print the sum totals for each month by pressing **PRINT** or **F4** (printer mode must be selected as output protocol on the serial port)






The data view function will display daily totals for all valid entries. Invalid data entries will be displayed as empty fields.

Press CLEAR to exit the monthly data view function.

HOW TO PRINT DATA LOG REPORTS

The data log reports are printed on a serial port that has its protocol set to TICKET PRINTING. The log data can be printed to any RS232 serial printer with a minimum column width of 32 characters or more. The data log function must first be enabled by accessing calibration parameter **DATA LOG SETUP**.

The serial port for COM1 or COM2 needs to be configured for TICKET PRINTING and must have the correct baud rate selected. For each display the **PRINT** or **F4** key can be pressed to request a report.



DATE: 21/05/2013

TIME: 11:05:28

Rate:	20.2 Tn/h
Speed:	200.5 ft/s
Total:	4 000 000 Tn
Load:	156 lb

Daily Total: 12 Tn

MONTHLY TOTALS (05)

JAN :	268.3 Tn
FEB :	260.1 Tn
MAR :	272.6 Tn
APL :	300.5 Tn
MAY :	270.9 Tn*
JUN :	263.0 Tn
JLY :	255.6 Tn
AUG :	249.2 Tn
SEP :	254.1 Tn
OCT :	260.5 Tn
NOV :	229.4 Tn
DEC :	241.8 Tn

TOTAL: 3216.0 Tn

DAILY TOTALS MONTH: 05

01/05/2013 :	7 012 lb
02/05/2013 :	10 800 lb
03/05/2013 :	20 001 lb
04/05/2013 :	30 001 lb
05/05/2013 :	65 001 lb
06/05/2013 :	40 001 lb
07/05/2013 :	16 200 lb
08/05/2013 :	13 800 lb
09/05/2013 :	10 200 lb
10/05/2013 :	6 012 lb
11/05/2013 :	2000 lb
12/05/2013 :	300 lb
13/05/2013 :	300 lb
14/05/2013 :	900 lb
15/05/2013 :	2600 lb
16/05/2013 :	4 002 lb
17/05/2013 :	5000 lb
18/05/2013 :	5 012 lb
19/05/2013 :	10 300 lb
20/05/2013 :	11 200 lb
21/05/2013 :	12 200 lb

TOTAL: 272 842 lb

HOW TO CONFIGURE THE TOTALIZER PULSE OUTPUT

The Totalizer Pulse Output is programmable to any totalized weight interval. The Pulse Output is active on IO POINT[0].

The pulse weight value must be entered in base units, lb or kg. The user can also change the pulse length in increments of seconds. This is useful for a PLC to determine if the pulse is valid by measuring the pulse length.

To set belt scale parameters, press **STOP** to exit to setup mode. Press the **MENU** key and use the UP/DOWN arrows to select **TOTAL PULSE SETUP**.

*Remember to save changes to parameters once finished using **F1** once you are back in the main screen.*

Enable Totalizer Pulse



This parameter enables the Totalizer Pulse Output on IO Point[0]. When this mode is enabled, the Batch function will be disabled. The Totalizer and the Batch functions cannot work at the same time.

Pulse Weight Value

This weight value must be entered in the calibration base units, (lb/kg). The weight pulse is battery backed up and will be valid even in the event of a power failure. If the belt scale is switched off, the LT350 will store/recall the last state of the totalizer.

Pulse Length Timer

The pulse length gets entered in increments of seconds. A pulse length of [0] equates to 500ms. The pulse length is useful for a PLC to determine if the pulse is valid by measuring the exact pulse length.




HOW TO CONFIGURE THE TOTALIZER PULSE OUTPUT

The Totalizer Pulse Output is programmable to any totalized weight interval – the weight pulse is battery backed up and will be valid even in the event of a power failure. If the belt scale is switched off, the LT350 will store/recall the last state of the totalization. The Pulse Output is active on IO POINT[0].

This weight value must be entered in base units, lb or kg. The user can also change the pulse length in increments of seconds. This is useful for a PLC to determine if the pulse is valid by measuring the pulse length.

To set belt scale parameters, press **STOP** to exit to setup mode. Press the **MENU** key and use the UP/DOWN arrows to select **TOTAL PULSE SETUP**.



HOW TO CONFIGURE THE INTERNAL CURRENT LOOP OUTPUT

The 4-20mA current loop interface can be configured to transmit belt rate, speed or the belt weight parameter. The user needs to enter the parameter minimum at 4mA and maximum at 20mA. If the belt mode is stopped or the value drops below the minimum value, a current less than 4mA will be transmitted to signal a fault condition. The 4-20mA is galvanically isolated and needs to be supplied with a power source of typically 24V DC from the target device such as a PLC. The receiver should measure the 4-20mA across a 100-200 ohm resistor as outlined in the diagram below.

To set belt scale parameters, press **STOP** to exit to setup mode. Press the **MENU** key and use the UP/DOWN arrows to select **CURRENT LOOP SETUP**.

*Remember to save changes to parameters once finished using **F1** once you are back in the main screen.*

Current Loop: Enable Current Loop Mode

This parameter enables the current loop output.

Current Loop: Minimum Value at 4mA


This is the parameter minimum value at 4 mA entered in base calibration units (kg/lb).

Current Loop: Maximum Value at 20mA

This is the parameter maximum value at 20 mA entered in base calibration units (kg/lb).

Current Loop: Parameter index


The belt parameter to use: rate(0), speed(1) weight(2)



HOW TO WIRE THE INTERNAL CURRENT LOOP OUTPUT TO A PLC

The 4-20mA is galvanically isolated and needs to be supplied with a power source of typically 24V DC from the target device. The receiver should measure the 4-20mA across a 100-200 ohm resistor as outlined in the diagram below.


To set parameters, press **STOP** to exit to setup mode. Press the **MENU** key and use the UP/DOWN arrows to select **CURRENT LOOP SETUP**.



HOW TO CONFIGURE SET POINT PARAMETERS

To set belt scale batch parameters, press **STOP** to exit to setup mode. Press the **MENU** key and use the UP/DOWN arrows to select **BELT BATCH SETUP**. These parameters set warning delay and belt startup timers. Once enabled, press **START** to begin batching using **F3** for the set point.

*Remember to save changes to parameters once finished using **F1** once you are back in the main screen.*



Enable Batch Mode

This parameter enables batch mode. Once the batch mode is enabled, the user needs to press **F3** to set the weigh set point. The user must then press **START** to activate a batch. If the printer is enabled on **COM1**, batch related data will be printed at the start and end of each batch draft. The batch process can be paused by pressing **STOP**. IO Point [0] controls the feeder bin gate.

Belt Start-up Timer

This parameter specifies the number of seconds to wait for the belt to come up to speed before opening the material supply gate. The same time period is applied after the set point is reached to give the belt enough time to clear material from the belt. IO Point [1] controls the belt motor.

Warning Start Timer

This parameter can be used for an alarm to warn that the belt is about to start after the following number of seconds. IO Point [2] controls start alarm.

IO Point[3] External Start Input

This IO point behaves exactly the same as the **START** key on the front panel. Can be wired for remote control.

IO Point[4] External Stop Input



This IO point behaves exactly the same as the **STOP** key on the front panel. Can be wired for remote control.

The batch counter is battery backed up as well as the belt set point which allows the system to recover from power interruptions. In order to reset the batch counter, the user need to enter calibration mode as described earlier on and disable and re-enable the batch function – this will also reset the batch counter. The batch counter is used with the printer reports when the COM port is configured as a printer port.

F3 is used to enter the set point for the belt batch function. The user can switch between base units lb or kg to Tonnes by pressing the **UNITS** key.

NOTE: If the Totalizer Pulse Output is enabled, the batch function will be disabled.

HOW TO WIRE THE SET POINT INTERFACE




HOW TO TRIM A SUMMING BOX

This is a general guideline for connecting multiple weigh idler load cells using a summing box. Each weigh idler typically has two load cells connected together using a two channel summing box. The output of each weigh idler summing box is then connected to the LT350 scale channels 1 up to 4.

If you opt for multiple idlers per single channel using a summing box - see section on multiple idlers to single channel below.

Trimming is a process of equalizing the output from multiple individual load cells, or from pairs of cells if using a summing box per weigh idler. When all errors except cell mismatch and cable extensions or reductions have been corrected, continue with the trimming procedures as follows :

1. Set all potentiometers fully counter-clockwise to give maximum signal output from all cells for the weigh idler to be adjusted.
2. Zero the indicator and place calibration test weights over each scale idler in turn. The amount of test weights used depends on the scale configurations; for specific recommendations, refer to Handbook 44 Field Manual. It is recommended to use a weight of at least 25% of the scale capacity not exceeding the maximum capacity of any individual load cell rating.
3. Record the value each time weight is placed on the scale and allow the scale to return to zero to check the friction on other mechanical problems. Select the weigh idler which has the lowest value as your reference point – this weigh idler will not be trimmed.
4. Now repeat the same test weight over each weigh idler and trim each with its potentiometer down to the correct weight. Above sequence might have to be repeated.
5. Tighten all wiring connections and plugs. Pull excess cable out of the enclosure and tighten cord grip assemblies to make it watertight.
6. Connect thick copper rod on outside of metal enclosure to earth ground of the scale chassis for a lightning bypass.





LT350BSI BELT SCALE - SENSE LINE MODE

COMMAND[52] SENSE LINE MODE, the CH1 becomes the sense line input while CH2 becomes the weigh idler scale input, while CH3 and CH4 are not used if sense lines are enabled.

If you opt for multiple idlers per single channel using a summing box - see section on multiple idlers to single channel.

This configuration is typically used for applications in an electrical noisy environment, or for long cable drops to minimize signal degradation. The user can also place a summing board at the end of the cable to facilitate a multiple weigh idler configuration.

NOTE: SENSE+/- must be paired with EX+/- at the summing box terminal end.



HOW TO SETUP MULTIPLE WEIGH IDLERS TO SINGLE CHANNEL

A single channel can be configured to connect to multiple scale idlers [1-10]. This is accomplished by using the menu item **CALIBRATION WIZARD** during calibration. Select the Calibration Wizard in calibration mode.

If you plan to use the 6 wire COMMAND[52] sense line mode, select it first before entering the wizard. See sense line mode for more details.

Using the Calibration Wizard in calibration mode

- make sure you select (1) channel for the scale idlers channels
- when asked how many weigh idlers you have installed on your belt enter the number of weigh idlers [1-10]

Guide for connecting multiple idlers to one channel with or without sense line mode

- If idler has more than one load cell - connect to a summing box
- Connect all weigh idlers to a summing box with one trim pot per weigh idler
- Preset the trimming pots as per summing box manual
- Connect summing box 4 wire to single channel - typically for short cable runs
- Connect summing box 6 wire to sense line mode - long cable runs
- Proceed to software calibration

Guide for calibrating the static weight for the weigh bridge.

- Remove weights from all idlers and do a dead load zero calibration
- Place equal weights on all weigh idlers and span calibrate to the sum of all weights.
- Remove weights from weigh idlers and add a weight to each weigh idler respectively
- Trim pot for each idler to the target weight as required
- Finally place all weights on each weigh idler and perform a span calibration again
- Repeat this sequence if so required

NOTE:

The weight displayed in the main calibration mode display is the summed weight for all weigh idlers and can be used to check each weigh idler during calibration.

However the weight displayed during the belt scale runtime display is the sum of all weigh idlers divided by the sum of the number of weigh idlers on the conveyor belt displayed as an average.


HOW TO SETUP SERIAL RS232 TO TRANSMIT WEIGHT DATA

To transmit RS232 ASCII strings containing weight information on a serial port COM1 or COM2. The following settings can be set:

- **COMMAND[26]** – check that the serial port is setup for RS232 mode.
- **COMMAND[27]** – serial baud rate 1200,4800,9600,14400,38400,57600 or 230400
- **COMMAND[28]** – protocol string format. The LT350 Belt scale data include speed, rate and total related data.
- **COMMAND[29]** – This command dictates whether the string is transmitted automatically or polled via an ASCII command set.

Windows HyperTerminal can be used to capture serial data strings at the same baud rate

Computer	LT350 COM1	Function
2	2	Rx ← Tx
3	3	Tx → Rx
5	7	Signal ground




NOTE: Many PCs today only support RS232 via USB which requires a USB to SERIAL cable

HOW TO SETUP RS485 TO TRANSMIT WEIGHT DATA

To change between RS232 and RS485 mode, the user must first unplug the COM1/2 cable. This configuration allows for long distance transmission over 100 meters. Unplug serial port, change to RS485 and then do the correct wire setup as outlined below before re-connecting:

- **COMMAND[26]** – Disconnect serial port connector and then set COM1/2 for RS485 mode. Port may get damaged if a cable is left plugged in that is not an RS485 type.
- **COMMAND[27]** – serial baud rate 1200,4800,9600,14400,38400,57600 or 230400
- **COMMAND[28]** – protocol string format. The LT350 Belt scale data include speed, rate and total related data.
- **COMMAND[29]** – This command dictates whether the string is transmitted automatically or polled via the ASCII command

Windows HyperTerminal can be used to capture serial data strings at the same baud rate



NOTE: A RS232 to RS422 converter is required for the computer

HOW TO SET SCALE FILTER PARAMETERS

The belt scale sensitivity can be adjusted for systems with vibration issues. Increasing the default values for more stable data. If a more responsive scale with high sensitivity is required the values of the filter parameters can be lowered. It is a good idea to always start with the default settings and start tuning the system accordingly.

PARAMETER (40) - SCALE AVERAGING FILTER

The scale averaging can be adjusted from (1 - 10) where 1 is no filtering with a very sensitive scale response. A value of 10 signify the largest filtering value. A high value is typically used for scale structures with lots of vibration.

PARAMETER (41) - SCALE FAST STEP THRESHOLD

This parameter is the difference between the new and the last sample and use it as a threshold point from (1-100). If the difference is larger than the threshold value we assume a fast step action to occur. Assume a belt that is settling at some weight level for some time. The averaging sample buffer will eventually be set at this weight. This condition might be interrupted by a full scale weight change. However, if we have selected a heavy scale averaging value in parameter (40), it will take some time, as long as a few second even, to update the averaging value to the new step level of the belt weight. The fast step threshold sets a value whereby the averaging filter will be re-populated with the new average weight value - we call this a fast step condition. To prevent the occurrences of false fast step triggers, we can increase the threshold (1-100) to a level that will hopefully eliminate the chances of a false fast trigger or spike.

PARAMETER (42) - SCALE FAST STEP ON/OFF

This parameter enable or disable the fast step parameter (41). Fast step is normally enabled with system default. If the fast step is disabled and you have heavy averaging set with parameter (40) you might notice that your system responds very sluggishly for large weight changes or step conditions and the only way to solve this is to lower the averaging value in parameter (40).

PARAMETER(53) – SCALE UPDATE RATE

This parameter determine the analog to digital channel scan rate (default 20 scans per second).

1-1 HALL EFFECT SPEED SENSOR




Table 1**HALL OPTIONS**

ACTIVATE DISTANCES ARE APPROXIMATE


USING NEFeB MAGNET

(.827I x .276W x .185H) 21 x 7 x 4.7

HAMLIN P/N 5812334000




Select Hall Option	Hall Type	Sensitivity Gauss (typ.)	Activate - d (in) mm
3M	3 Wire Switch	130	12.5mm
3H	3 Wire Switch		
3L			



1-2 HALL EFFECT MAGNETIC SETUP

The Hall Effect sensor has a red (LED) light emitting diode that will illuminate if a magnet south pole is within 10 mm gap of the LED. The LED can be used to check for south pole polarity orientation of magnets and proper alignment. The magnet south pole should cross within at least 10 mm from the LED of the hall effect sensor.



Care should be taken to make sure that the distance of magnet wheel to Hall Effect will be consistent over the long term. Systemic erosion of structures must be factored to prevent the wheel from eventually finding itself outside the maximum 18 mm distance gap from the Hall Effect sensor.

STATIC DISCHARGE ISSUES

It is very common for conveyor belts to generate static charge between the belt and the rollers and in this case the belt speed sensor. This static charge, if not properly drained, can destroy the Hall Effect sensor.


In order to mitigate static problems, a single layer of aluminum foil adhesive tape can be placed directly over the face of the sensor covering the sensor body in order to dissipate the static charge away from the sensor body to the structure.

1-3 IO STATUS VIEW

The user can monitor and diagnose the Hall Effect sensor on IO Point[7] by exiting the belt Scale mode and use the **MENU** and arrows to navigate to :
[IO Status View]

To exit Belt Scale run mode, press STOP repeatedly until prompted to exit to calibration mode.

The IO Status View screen shows all eight IO points[0-7] in real time and will also increment the pulse counter register for each magnetic transition across the Hall Effect sensor.



The user can clear the pulse registers by pressing [0].

[<][C][T][TTTTTTTTTTTTTT][,][U][:][D][C][C][>]			
0	1		
[<]	[C]		(belt number)
2	3	15	16
[T]	[T]	[,]	[U]
			(belt Total)
17	18		
[:]	[D]		(belt status)
19	20	21	
[C]	[C]	[>]	(belt checksum)

0	<	1 byte	String start delimiter												
1	C	1 byte	Belt scale channel number [1-4]												
2	T	1 byte	Parameter start delimiter												
3	T	12 bytes	Belt Total – 12 digits												
15	,	1 byte	Parameter separator												
16	U	1 byte	Total units: L(lb), K(kg) or T(tonnes)												
17	:	1 byte	Parameter start delimiter												
18	D	1 byte	System state Diagnostics <table><tr><td>[SPACE]</td><td>Indicates normal operation</td></tr><tr><td>O</td><td>Indicates scale over capacity</td></tr><tr><td>N</td><td>Indicates scale negative</td></tr><tr><td>M</td><td>Indicates motion on scale</td></tr><tr><td>Z</td><td>Scale at zero weight [Z] or not at zero [SPACE]</td></tr><tr><td>H</td><td>Integrator halted</td></tr></table>	[SPACE]	Indicates normal operation	O	Indicates scale over capacity	N	Indicates scale negative	M	Indicates motion on scale	Z	Scale at zero weight [Z] or not at zero [SPACE]	H	Integrator halted
[SPACE]	Indicates normal operation														
O	Indicates scale over capacity														
N	Indicates scale negative														
M	Indicates motion on scale														
Z	Scale at zero weight [Z] or not at zero [SPACE]														
H	Integrator halted														
19	C	1 byte	Upper checksum hex byte for inverted checksum of bytes 0-18												
20	C	1 byte	Lower checksum hex byte for inverted checksum of bytes 0-18												
21	>	1 byte	String end delimiter												
22	CR														
23	LF														

[<][C][T][TTTTTTTTTTTT][,][U][S][SSSSSSSS][,][U][:][D][C][C][>]

0	1			
[<]	[C]			(belt number)
2	3	15	16	
[T]	[T]	[,]	[U]	(belt total)
17	18	26	27	
[S]	[S]	[,]	[U]	(belt speed)
28	29			
[:]	[D]			(belt state)
30	31	32		
[C]	[C]	[>]		(checksum)

0	<	1 byte	String start delimiter	
1	C	1 byte	Belt scale channel number [1-4]	
2	T	1 byte	Parameter start delimiter	
3	T	12 bytes	Belt Total – 12 digits	
15	,	1 byte	Parameter separator	
16	U	1 byte	Total units: L(lb), K(kg) or T(tonnes)	
17	S	1 byte	Parameter start delimiter	
18	S	8 bytes	Belt speed	
26	,	1 byte	Parameter separator	
27	U	1byte	Belt speed units: ft/s, ft/m, ft/h, M/s, M/m, M/h	
28	:	1 byte	Parameter start delimiter	
29	D	1 byte	Belt State	
			[SPACE]	Indicates normal operation
			O	Indicates scale over capacity
			N	Indicates scale negative
			M	Indicates motion on scale
			Z	Scale at zero weight [Z] or not at zero [SPACE]
H	Integrator halted			
30	C	1 byte	Upper checksum hex byte for inverted checksum of data 0-29	
31	C	1 byte	Lower checksum hex byte for inverted checksum of data 0-29	
32	>	1 byte	String end delimiter	
33	CR			
34	LF			

[<][C][T][TTTTTTTTTTTT][,][U][S][SSSSSSSS][,][U][R][RRRRRRRR][,][U][:][D][C][C][>]

0	1			
[<]	[C]			(belt number)
2	3	15	16	
[T]	[T]	[,]	[U]	(belt total)
17	18	26	27	
[S]	[S]	[,]	[U]	(belt speed)
28	29	37	38	
[R]	[R]	[,]	[U]	(belt rate)
39	40			
[:]	[D]			(belt state)
41	42	43		
[C]	[C]	[>]		(checksum)

0	<	1 byte	String start delimiter												
1	C	1 byte	Belt scale channel number [1-4]												
2	T	1 byte	Parameter start delimiter												
3	T	12 bytes	Belt Total – 12 digits												
15	,	1 byte	Parameter separator												
16	U	1 byte	Total units: L(lb), K(kg) or T(tonnes)												
17	S	1 byte	Parameter start delimiter												
18	S	8 bytes	Belt speed												
26	,	1 byte	Parameter separator												
27	U	1byte	Belt speed units: ft/s, ft/m, ft/h, M/s, M/m, M/h												
28	R	1 byte	Parameter start delimiter												
29	R	8 bytes	Belt rate												
37	,	1 byte	Parameter separator												
38	U	1byte	Belt speed units: kg/s/m/h, lb/s/m/h, T/s/m/h												
39	:	1 byte	Parameter start delimiter												
40	D	1 byte	<div>Belt State<table><tr><td>[SPACE]</td><td>Indicates normal operation</td></tr><tr><td>O</td><td>Indicates scale over capacity</td></tr><tr><td>N</td><td>Indicates scale negative</td></tr><tr><td>M</td><td>Indicates motion on scale</td></tr><tr><td>Z</td><td>Scale at zero weight [Z] or not at zero [SPACE]</td></tr><tr><td>H</td><td>Integrator halted</td></tr></table></div>	[SPACE]	Indicates normal operation	O	Indicates scale over capacity	N	Indicates scale negative	M	Indicates motion on scale	Z	Scale at zero weight [Z] or not at zero [SPACE]	H	Integrator halted
[SPACE]	Indicates normal operation														
O	Indicates scale over capacity														
N	Indicates scale negative														
M	Indicates motion on scale														
Z	Scale at zero weight [Z] or not at zero [SPACE]														
H	Integrator halted														
41	C	1 byte	Upper checksum hex byte for inverted checksum of data 0-40												
42	C	1 byte	Lower checksum hex byte for inverted checksum of data 0-40												
43	>	1 byte	String end delimiter												

Primary Units	Multiplication Factor	Secondary Units	
Pounds (lb)	0.453592	kilograms	kg
	0.0005	Short tons	TN
	0.000446	Long tons	LT
	0.000453	Metric tons	T
Primary Units	Multiplication Factor	Secondary Units	
Kilograms (kg)	2.20462	pounds	lb
	0.001102	Short tons	TN
	0.000984	Long tons	LT
	0.001000	Metric tons	T
Primary Units	Multiplication Factor	Secondary Units	
Short Tons (TN)	2000.00	pounds	lb
	907.185	kilograms	kg
	0.892857	Long tons	TN
	0.907185	Metric tons	T
Primary Units	Multiplication Factor	Secondary Units	
Metric Tons (T)	2204.62	pounds	lb
	1000.00	kilograms	kg
	1.10231	Short tons	TN
	0.984207	Long tons	LT
Primary Units	Multiplication Factor	Secondary Units	
Long Tons (LT)	2240.00	pounds	lb
	1016.05	kilograms	kg
	1.1200	Short tons	TN
	1.01605	Metric Tons	T

